


IPTV function User Guide


1.Free IPTV

some customer may want to use their own link which find from internet,as below:

- ① create one file called **tvlist.txt** on computer




- ② input the link which you find using format as:
channelname+space+channellink+space+\$categoryname\$




Or(this format have not category):


channelname+space+channellink



- ③ copy the tvlist.txt to usb drive and insert it to the box
- ④ also you can copy the m3u format to usb drive, the STB support the format (Note: the file name must be tvlist.m3u)
- ⑤ enter Network App and click Free IPTV, you can see playing tvlist link channel (Note: the network must be connected success)




Free IPTV




Click the ok key,you will see channel list,press remote **red** button to save the TV channel.




press remote play▶ key ,you can see category








2. NEW TV+

The NEW TV+ is the free iptv for customer, you can see the status in camds setup







3. Other IPTV protocol

some customer may want to use their own or parter IPTV server. As below:

- ① query our
- ② deliver the protocol to our
- ③ add the IPTV to Network App

Note: some IPTV protocol run by the STB may not be smoothly.


4.Stalker

We will enable this function as customer request. Enter Stalker from Network App ,you can see the login menu




You can input the stalker portal accounts use keyboard manual. Also you can input the accounts as below:

- ① create one file called **stalker.txt** on computer



②input the account which you find using fomate as:



```
stalker.txt - 记事本
文件(F) 编辑(E) 格式(O) 查看(V) 帮助(H)
{
  "MultiPortal": [
    {
      "mac": "00:1A:79:D1:A6:1F",
      "server": "XXXXXXXXXX",
      "login": "username",
      "password": "password"
    },
    {
      "mac": "00:1A:79:35:42:FC",
      "server": "XXXXXXXXXXXXXX",
      "login": "username",
      "password": "password"
    }
  ]
}
```

③copy the stalker.txt to usb drive,insert to the STB
Press red button to load the config file.Maximum we can support 5 portals,but can be added more as you like.

Note:make sure your stalker.txt content comply with the formal JSON(JavaScript Object Notation) format.