


# How to Reset OPENBOX VX

If you are experiencing problems and box is not working properly. Most of the times Resetting to the default settings can fix the problems.

*Please note that Resetting will erase all saved data.*

- Go to Settings



- Go to **Restore** and then **Reset**. Box will restart and will take few minutes to load. Please wait for the box to load.

